




# Agile Installation Guide - Electric 2 Column




#### **Parts:**



#### **Parts:**

















# **Agile**Installation Guide - Electric 2 Column





# Step 4 16 x M5x10


# **Agile**Installation Guide - Electric 2 Column













### **Agile**Installation Guide - Electric 2 Column

# Step 10 12 x ST5.0x23 \* Minimum 20mm wider than screen www.freewaydesign.net


# **Agile**Installation Guide - Electric 2 Column





# Optional Desk Hung Screen Installation Guide















Installation Guide - Electric 2 Column





#### **Completed**














### **Agile**Directions For Use

#### IMPORTANT!

Please carefully read the assembly manual and direction for use prior to instalment, use and maintenance of the table frame to gain a complete understanding of its contents. It provides you with important information about the safety, use, installation and maintenance of the table.

WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.

#### **SAFETY**

- •The table must be used in a safe manner. Inappropriate use may cause damage to the table and/or cause bodily harm to the user or persons nearby.
- •Do not tamper with electrical components as this may lead to serious bodily harm.
- •Only connect the electric table frames to the prescribed mains power voltage.
- •Do not use the table frame to lift people.
- •Please retain this operation manual and pass it on to any future owner.

#### USAGE

- •The height-adjustable table is designed for use in dry work environments only.
- •The table height is infinitely adjustable within its height range so that it can be set to the user's most ergonomic working height. The user should seek professional help to establish their optimum working height.
- •The table has been designed as a devise to elevate the users work surface and associated office peripherals. Do not use the table frame for any other purposes than that which it has been designed for. Any other use is at user's own risk!
- •Do not crawl, lie or move around under the table frame, and do not sit or stand on the table frame.
- •CHILDREN should only use the table when supervised by adults.
- •Liability: The manufacturer accepts under no circumstances warranty claims or liability claims for damages arising from improper use or handling of the table frame other than that described in this operation manual.

#### SET UP AND INSTALLATION

Assemble the table frame according to the assembly instructions on pages 4 - 12.

- •Place the table in a safe distance from window frames, radiators, furniture etc. so that persons cannot become trapped.
- •Level the table with the adjustable feet ensuring that the table is stable.
- •Check that no cables can get jammed.
- •Connect the table to the 110 or 230 VAC power outlet.

The table is now ready for use.

#### **MAINTENANCE**

•The table does not require any maintenance by the user

•The table is only to be cleaned with a wrung cloth.

#### **TECHNICAL DATA**


Height Range: 680-1130mm including worktop

Speed: ~22mm/s

Input Voltage: 100-240V AC 50-60Hz


Output Voltage: 24V DC 2.0A

Duty Cycle: 10% 2min on 18min off







# Agile Installation Guide - Electric 3 Column




#### **Parts:**



#### **Parts:**







24 x M8x10













4 x M5x15

20 x M5x10


16 x M8x10








# Step 3 4 x Adjustable Glide


# Step 4 16 x M5x10













## **Agile**Installation Guide - Electric 3 Column

# Step 10 16 x ST5.0x22 a= \* Minimum 20mm wider than screen www.freewaydesign.net


## **Agile**Installation Guide - Electric 3 Column









# **Agile**Installation Guide - Electric 3 Column





## **Agile**Installation Guide - Electric 3 Column








## **Completed**
















### **IMPORTANT**

Please carefully read the assembly manual and direction for use prior to instalment, use and maintenance of the table frame to gain a complete understanding of its contents. It provides you with important information about the safety, use, installation and maintenance of the table.

WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.

#### SAFETY

- •The table must be used in a safe manner. Inappropriate use may cause damage to the table and/or cause bodily harm to the user or persons nearby.
- •Do not tamper with electrical components as this may lead to serious bodily harm.
- •Only connect the electric table frames to the prescribed mains power voltage
- •Do not use the table frame to lift people.
- •Please retain this operation manual and pass it on to any future owner.

#### USAGE

- •The height-adjustable table is designed for use in dry work environments only.
- •The table height is infinitely adjustable within its height range so that it can be set to the user's most ergonomic working height. The user should seek professional help to establish their optimum working height.
- •The table has been designed as a devise to elevate the users work surface and associated office peripherals. Do not use the table frame for any other purposes than that which it has been designed for. Any other use is at user's own risk!
- •Do not crawl, lie or move around under the table frame, and do not sit or stand on the table frame.
- •CHILDREN should only use the table when supervised by adults.
- •Liability: The manufacturer accepts under no circumstances warranty claims or liability claims for damages arising from improper use or handling of the table frame other than that described in this operation manual.

### SET UP AND INSTALLATION

Assemble the table frame according to the assembly instructions on pages 4 - 12.

- •Place the table in a safe distance from window frames, radiators, furniture etc. so that persons cannot become trapped.
- •Level the table with the adjustable feet ensuring that the table is stable.
- •Check that no cables can get jammed.
- •Connect the table to the 110 or 230 VAC power outlet.

The table is now ready for use.

### **MAINTENANCE AND DEFECTS**


- The table does not require any maintenance by usage as described in chapter 2 in the directions for use.
- The table is only to be maintained with a wrung cloth.
- In the event of the occurrence of jarring sounds during operation, STOP using the table and please contact the dealer.

### **TECHNICAL DATA**

Height Range: 610-1230mm including worktop


Speed: ~30mm/s

Input Voltage: 100-240V AC 50-60Hz Output Voltage: 24V DC 2.0A Duty Cycle: 10% 2min on 18min off







# Agile Installation Guide - Electric 2 Column




### **Parts:**









4 x M8x10




























## Step 4 Worktop Length 1200mm 1125mm 1500mm 1425mm 1800mm 1725mm 2100mm 2025mm


## **Agile**Installation Guide - Electric 2 Column




# **Agile**Installation Guide - Electric 2 Column











### **Completed**


























## **Optional Desk Hung Screen**


Installation Guide

### **Completed**




# Optional Cable Tray Installation Guide





# Optional Cable Tray Installation Guide



#### IMPORTANT!

Please carefully read the assembly manual and direction for use prior to instalment, use and maintenance of the table frame to gain a complete understanding of its contents. It provides you with important information about the safety, use, installation and maintenance of the table.

WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.

#### **SAFETY**

- •The table must be used in a safe manner. Inappropriate use may cause damage to the table and/or cause bodily harm to the user or persons nearby.
- •Do not tamper with electrical components as this may lead to serious bodily harm.
- •Only connect the electric table frames to the prescribed mains power voltage.
- •Do not use the table frame to lift people.
- •Please retain this operation manual and pass it on to any future owner.

#### USAGE

- •The height-adjustable table is designed for use in dry work environments only.
- •The table height is infinitely adjustable within its height range so that it can be set to the user's most ergonomic working height. The user should seek professional help to establish their optimum working height.
- •The table has been designed as a devise to elevate the users work surface and associated office peripherals. Do not use the table frame for any other purposes than that which it has been designed for. Any other use is at user's own risk!
- •Do not crawl, lie or move around under the table frame, and do not sit or stand on the table frame.
- •CHILDREN should only use the table when supervised by adults.
- •Liability: The manufacturer accepts under no circumstances warranty claims or liability claims for damages arising from improper use or handling of the table frame other than that described in this operation manual.

#### SET UP AND INSTALLATION

Assemble the table frame according to the assembly instructions on pages 4 - 12.

- •Place the table in a safe distance from window frames, radiators, furniture etc. so that persons cannot become trapped.
- •Level the table with the adjustable feet ensuring that the table is stable.
- •Check that no cables can get jammed.
- •Connect the table to the 110 or 230 VAC power outlet.

The table is now ready for use.

#### **MAINTENANCE**

•The table does not require any maintenance by the user

•The table is only to be cleaned with a wrung cloth.

#### **TECHNICAL DATA**


Height Range: 680-1130mm including worktop

Speed: ~22mm/s

Input Voltage: 100-240V AC 50-60Hz


Output Voltage: 24V DC 2.0A

Duty Cycle: 10% 2min on 18min off







# Agile Installation Guide - Electric 3 Column




### **Parts:**








8 x M8x10























## Step 5 Worktop Length 1200mm 1125mm 1500mm 1425mm 1800mm 1725mm 2100mm 2025mm




# Step 7 8 x ST5.0x23


# **Agile**Installation Guide - Electric 3 Column







## **Completed**
























# Optional Cable Tray Installation Guide





# Optional Cable Tray Installation Guide



#### **IMPORTANT**

Please carefully read the assembly manual and direction for use prior to instalment, use and maintenance of the table frame to gain a complete understanding of its contents. It provides you with important information about the safety, use, installation and maintenance of the table.

WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.

#### SAFETY

- •The table must be used in a safe manner. Inappropriate use may cause damage to the table and/or cause bodily harm to the user or persons nearby.
- •Do not tamper with electrical components as this may lead to serious bodily harm.
- •Only connect the electric table frames to the prescribed mains power voltage
- •Do not use the table frame to lift people.
- •Please retain this operation manual and pass it on to any future owner.

#### USAGE

- •The height-adjustable table is designed for use in dry work environments only.
- •The table height is infinitely adjustable within its height range so that it can be set to the user's most ergonomic working height. The user should seek professional help to establish their optimum working height.
- •The table has been designed as a devise to elevate the users work surface and associated office peripherals. Do not use the table frame for any other purposes than that which it has been designed for. Any other use is at user's own risk!
- •Do not crawl, lie or move around under the table frame, and do not sit or stand on the table frame.
- •CHILDREN should only use the table when supervised by adults.
- •Liability: The manufacturer accepts under no circumstances warranty claims or liability claims for damages arising from improper use or handling of the table frame other than that described in this operation manual.

#### SET UP AND INSTALLATION

Assemble the table frame according to the assembly instructions on pages 4 - 12.

- •Place the table in a safe distance from window frames, radiators, furniture etc. so that persons cannot become trapped.
- •Level the table with the adjustable feet ensuring that the table is stable.
- •Check that no cables can get jammed.
- •Connect the table to the 110 or 230 VAC power outlet.

The table is now ready for use.

#### **MAINTENANCE AND DEFECTS**


- The table does not require any maintenance by usage as described in chapter 2 in the directions for use.
- The table is only to be maintained with a wrung cloth.
- In the event of the occurrence of jarring sounds during operation, STOP using the table and please contact the dealer.

#### **TECHNICAL DATA**

Height Range: 610-1230mm including worktop

Speed: ~30mm/s

Input Voltage: 100-240V AC 50-60Hz Output Voltage: 24V DC 2.0A Duty Cycle: 10% 2min on 18min off







Installation Guide - Electric 2 Column Left Hand Return For Single & Double Desk




### **Parts:**








Installation Guide - Electric 2 Column Left Hand Return For Single & Double Desk



Installation Guide - Electric 2 Column Left Hand Return For Single & Double Desk





Option 1 - Electric 2 Column Left Hand Return for Single Desk

Go to page 7

Option 2 - Electric 2 Column Left Hand Return for Double Desk

Go to page 11

Installation Guide - Electric 2 Column Left Hand Return For Single & Double Desk


**Option 1: Single Desk and Return** 

Step 4




#### **IMPORTANT!**


REFER TO SETPS 1-4 OF SINGLE-SIDED ELECTRIC 2 COLUMN DESK INSTALLATION GUIDE TO ASSEMBLE DESK FRAME.




Installation Guide - Electric 2 Column Left Hand Return For Single & Double Desk









## **Completed**




Installation Guide - Electric 2 Column Left Hand Return For Single & Double Desk







Installation Guide - Electric 2 Column Left Hand Return For Single & Double Desk







#### **Completed**






Installation Guide - Electric 2 Column Right Hand Return For Single & Double Desk




Installation Guide - Electric 2 Column Right Hand Return For Single & Double Desk

#### **Parts:**









Installation Guide - Electric 2 Column Right Hand Return For Single & Double Desk





Installation Guide - Electric 2 Column Right Hand Return For Single & Double Desk










4 x M8x25






Option 1 - Electric 2 Column Right Hand Return for Single Desk

Go to page 7


Option 2 - Electric 2 Column Right Hand Return for Double Desk


Go to page 11

Installation Guide - Electric 2 Column Right Hand Return For Single & Double Desk












#### **Completed**







Installation Guide - Electric 2 Column Right Hand Return For Single & Double Desk




Installation Guide - Electric 2 Column Right Hand Return For Single & Double Desk








#### **Completed**







# Agile Installation Guide - Electric 3 Column




#### **Parts:**








8 x M8x10






4 x M8x10







16 x M8x10














### **Step 5a**























#### **IMPORTANT**

Please carefully read the assembly manual and direction for use prior to instalment, use and maintenance of the table frame to gain a complete understanding of its contents. It provides you with important information about the safety, use, installation and maintenance of the table.

WARNING: FAILURE TO COMPLY WITH OR OBSERVE ALL ASSEMBLY, SAFETY AND OPERATION INSTRUCTIONS REGARDING THE USE OF THIS PRODUCT MAY RESULT IN SERIOUS BODILY INJURY.

#### SAFETY

- •The table must be used in a safe manner. Inappropriate use may cause damage to the table and/or cause bodily harm to the user or persons nearby.
- •Do not tamper with electrical components as this may lead to serious bodily harm.
- •Only connect the electric table frames to the prescribed mains power voltage
- •Do not use the table frame to lift people.
- •Please retain this operation manual and pass it on to any future owner.

#### USAGE

- •The height-adjustable table is designed for use in dry work environments only.
- •The table height is infinitely adjustable within its height range so that it can be set to the user's most ergonomic working height. The user should seek professional help to establish their optimum working height.
- •The table has been designed as a devise to elevate the users work surface and associated office peripherals. Do not use the table frame for any other purposes than that which it has been designed for. Any other use is at user's own risk!
- •Do not crawl, lie or move around under the table frame, and do not sit or stand on the table frame.
- •CHILDREN should only use the table when supervised by adults.
- •Liability: The manufacturer accepts under no circumstances warranty claims or liability claims for damages arising from improper use or handling of the table frame other than that described in this operation manual.

#### SET UP AND INSTALLATION

Assemble the table frame according to the assembly instructions on pages 3 - 9.

- •Place the table in a safe distance from window frames, radiators, furniture etc. so that persons cannot become trapped.
- •Level the table with the adjustable feet ensuring that the table is stable.
- •Check that no cables can get jammed.
- •Connect the table to the 110 or 230 VAC power outlet.

The table is now ready for use.

#### **MAINTENANCE**

•The table does not require any maintenance by the user

•The table is only to be cleaned with a wrung cloth.

#### **TECHNICAL DATA**

Height Range: 635-1290mm including worktop

Speed: ~30mm/s

Input Voltage: 90-230V AC 50-60Hz, 300VA

Output Voltage: 24V DC Max.10A

Duty Cycle: 10% max. 2min on/18min off

