

UNIFLIP TABLES

Care and Maintenance

Annual Check

At least every 12 months, ensure all the mounting screws attaching table tops and the flip mechanisms are still working correctly.

Top Care

Uniflip tables are supplied standard with melamine tops. Clean tops regularly by wiping them down with a damp cloth and a general purpose cleaner/detergent. For best results use streak free glass cleaner.

Stain and Mark Removal

- Stubborn marks or stains apply Handy Andy or diluted Janola (1 part to 3 parts water), then wipe down with a warm damp cloth.
- Smearing, finger marks, marking from cold or hot dishes, stickiness apply 1 or 2 applications of acetone (available at pharmacies) and wipe over with dry cloth.
- Felt pen or dry marker use methylated spirits or acetone
- Paint use acetone or thinners (from a paint shop)
- Glue contact type use Ados Solvent N (from a paint shop)

Follow on with streak free glass cleaner to remove any residues.

Frame Care

Keep the plastic and metal components of your table clean by wiping them down with a damp cloth and a general purpose cleaner/detergent. For best results use streak free glass cleaner.