





Anvil 2 – User 90° Workstation


Assembly Instructions

Anvil 2-User 90° Workstation

Components List




Axis Worktop



1 x L & R Leg Pair

EL




1 x End Leg

BL




1 x 2-Way 90° Leg

SL




2 x Pair AXKDBRAC

B



4 x Pair AXKDSPIGE

C



4 x Rail

R



24 - M6 x 20



16 - M8 x 16



12 - ST6 x 23



16 - ST5 x 70


Anvil 2-User 90° Workstation

Assembly Instructions

STEP 1:



8 - M6 x 20




Anvil 2-User 90° Workstation

Assembly Instructions

STEP 2:




8 - M6 x 20



STEP 3:





8 - M6 x 20



Anvil 2-User 90° Workstation

Assembly Instructions

STEP 4:




STEP 5:



12 - ST6 x 23




8 - ST5 x 70



Anvil 2-User 90° Workstation

Assembly Instructions

Complete:





Sydney 02 8188 2732

Melbourne 03 9111 0315

Brisbane 07 3733 1923

Adelaide 08 7111 0810

Perth 08 9468 2707

info@olgoffice.com

myolg.online | olgoffice.com | officedesigner.net | motionoffice.com