

OLG




Astral Executive.

Install Instructions


Astral Executive Chair

Components List



Back Frame

A




Arm 1

B



Arm 2

C



Seat Pan with Mechanism

D




Gas Cylinder

E



Gaslift Sleeve

F




Base

G




Castor Wheel

H



Headrest

I



2 - M8 x 30

J



4 - M8 Washer

K




2 - M8 x 60

L



2 - M6 x 12

M



M6

N




O

Astral Executive Chair


Install Instructions

1




2

J



2 - M8 x 30



Astral Executive Chair


Install Instructions

3

L



2 - M8 x 60




4

M



2 - M6 x 12



Astral Executive Chair

Install Instructions

5





02 8188 2732

info@olgoffice.com

in OLG-Office

myolg.online | olgoffice.com

Aspirational design meets
functional solutions.