Agile Electric 2C Handset Programming Instructions

Program Descending Anti-Collision Level.

- 1. Press and hold M4 key until you hear you hear two audible beeps. LCD screen will display mode "A".
- 2. Press M4 again to select mode "A"
- 3. Use \sim or \sim key to adjust anti-collision sensitivity level to "1, 2, 3, 4 or 5"
- 4. Press M3 key to save and return to mode level.
- 5. Press M3 key to exit program.

Program LCD Screen to Display Centimeters or Inches

- 1. Press and hold M4 key until you hear you hear two audible beeps. LCD screen will display mode "A".
- 2. Press the \frown or \checkmark key to navigate to mode "b"
- 3. Press M4 to select mode "b"
- 4. Press the \frown or \checkmark key to switch between 1(cm) and 2(inches).
- 5. Press M4 to select desired setting.
- 6. Press M3 key to save and return to mode level.
- 7. Press M3 key to exit program.

Program Minimum Height Displayed On LCD Screen

- 1. Press and hold M4 key until you hear you hear two audible beeps. LCD screen will display mode "A".
- 2. Press the \frown or \checkmark key to navigate to mode "C"
- 3. Press M4 to select mode "C"
- 4. Press the \frown or \checkmark key to set the minimum height. Absolute minimum is 50cm.
- 5. Press M3 key to save and return to mode level.
- 6. Press M3 key to exit program.

Program Maximum Desk Height

- 1. Press and hold M4 key until you hear you hear two audible beeps. LCD screen will display mode "A".
- 2. Press the \frown or \checkmark key to navigate to mode "d"
- 3. Press M4 to select mode "d"
- 4. Press the \frown or \checkmark key to set the maximum height.
- 5. Press M3 key to save and return to mode level.
- 6. Press M3 key to exit program.

Program Ascending Anti-Collision Level.

- 1. Press and hold M4 key until you hear you hear two audible beeps. LCD screen will display mode "A".
- 2. Press the \frown or \checkmark key to navigate to mode "E"
- 3. Press M4 again to select mode "E"
- 4. Use ∧ or ∨ key to adjust anti-collision sensitivity level to "1" (default) or "2" (when lifting load is above 80kg)
- 5. Press M3 key to save and return to mode level.
- 6. Press M3 key to exit program.